


## Vigor130 » VDSL Quick Start Guide

### Configure your computer's network

Connect your computer to the Vigor130 with an Ethernet cable (supplied). Ensure your computer is obtaining an IP address automatically.

### Connect to the Web Interface

Open your Web Browser (e.g. Internet Explorer, Google Chrome or Mozilla Firefox), enter **http://192.168.1.1/** into the address bar, and press the Enter key on your keyboard.



You should be asked for a username and password. Enter **admin** into the username field, leave the password field blank and click **OK**.

### Quick Start Wizard

On the left-hand navigation menu, click **Quick Start Wizard**. You will be prompted to set a new password. This is the password used to access the modem configuration in future, not the password for your internet connection. Type the same password into both fields and click **Next**.

**1. Enter login password**

Please enter an alpha-numeric string as your **Password** (Max 23 characters).

New Password

Confirm Password

< Back   Next >   Finish   Cancel

Ensure the settings on this screen are:

- **VPI**                    0
- **VCI**                    100
- **Protocol**            PPPoA VC MUX
- **Fixed IP**            No (Dynamic IP)

All other fields should be blank. Click **Next**.

Quick Start Wizard

Connect to Internet

Protocol

For ADSL Only:

Encapsulation

VPI

VCI

Fixed IP  Yes  No (Dynamic IP)

IP Address

Subnet Mask

Default Gateway

Primary DNS

Second DNS

< Back   Next >   Finish   Cancel

*(instructions continue overleaf)*

Enter the username and password *provided to you by your Internet Service Provider*. Username should be in the form of an email address, and the password will need to be entered into both the Password and Confirm Password fields. All fields are case sensitive. Ensure the **Always On** checkbox is ticked.

**3. Set PPPoE / PPPoA**

ISP Name	<input type="text"/>
User Name	change.me@isp
Password	*****
Confirm Password	*****
<input checked="" type="checkbox"/> Always On	
Idle Timeout	-1 Seconds

Click **Next** and then **Finish**. The modem will reboot, wait for a minute or two to give it time to connect.

## VLAN ID.

Some ISPs require the insertion of VLAN ID 10. If this is the case simply add this in after the router has rebooted as below. Reboot again & check the online status screen for confirmation that the circuit has come up.

Internet Access >> General Setup

**WAN 1**

Display Name:	<input type="text"/>
Physical Mode:	VDSL2
DSL Mode:	VDSL2 only v
VLAN Tag insertion :	Enable v
Tag value:	10 (0~4095)
Priority:	0 (0~7)

**Note :** In DSL auto mode, the router will reboot automatically while switching between VDSL2 and ADSL lines.

## Need help?

We're available 9:00am to 5:00pm, Monday to Friday.

Phone: 09 415 4182 Email: [tech@snappernet.co.nz](mailto:tech@snappernet.co.nz)

Firmware updates are available free of charge from [www.draytek.net.nz](http://www.draytek.net.nz)

## Advanced Users: PPPoA passthrough mode

Most Broadband routers (e.g. Vigor2910 or a PC running pfSense) are only able to authenticate using PPPoE, but New Zealand ADSL requires PPPoA authentication. Vigor ADSL modems can be configured for PPPoA/PPPoE passthrough to allow you to connect a broadband router such as the Vigor2910 or a Smoothwall box to an ADSL line.

All you need to do is check the box under **PPPoE Pass-through** on the **Internet Access > PPPoE / PPPoA** page of the Vigor web interface.

### PPPoE Pass-through

For Wired LAN

Then set up your Broadband router or firewall as a PPPoE device, providing it with your ISP's username and password. **Ensure you leave the Service Name field on your router/firewall blank.** Your Broadband router will be assigned your Public IP address and directly control your connection.